

# WIDTHS



## NOMINAL 4"

Actual coverage widths vary depending on the chosen profile. Tongue and groove (stapled) or grooved (nailed) **profiles** are available.

Old Cottage style with rabbeted bevel and modern style with v-joint.

**Higher installation cost** due to slower installation progress and higher number of fastenings.

**Increased stability** due to more closely-spaced fastenings.



## NOMINAL 5"

**Exclusively** for white cedar v-joints.

Tongue and groove **profiles** (stapled) only.



## NOMINAL 6"

Tongue and groove (stapled) or grooved (nailed) **profiles** are available.

A selection of the most installed models.

**The most popular width** in terms of raw material optimization, cost, style, aesthetics, easier installation, etc.



## NOMINAL 8"

Limits the **effect of grooves** on larger surfaces.

Installation progresses faster.

Grooved **profiles** (nailed) only.

Models wider than 6" **require more closely-spaced fastenings**. The use of nails with heads is therefore required; they are fastened through the boards and spaced according to instructions.